

Part No. EF46.27266.620 Part No. EG46.27266.620

**Description:** Rotary selector switch.

**Operating range:** 7 Position Clockwise Increase.

**Application:** 6 Heat hotplate control.

Electrical rating: 16 amps, 240 volts, A.C.

**Knob:** EF524.151A

Original user: O.E.M. Part No.


Email, Simpson, Electrolux 0543001528 Braemar 073.203

## Wiring diagram.

## 

Active Neutral

## **Mounting dimensions:**



**Warnings:** To be installed only by a registered electrician. Isolate appliance before comencing service.

