




Mastercool® Inc.

"World Class Quality"

70057-A

ECCENTRIC FLARING TOOL INSTRUCTIONS



SET-UP

1. Rotate "T" handle and cone driving screw counter clockwise to allow clearance for inserting the clamp bar.
2. Position the clamp bar with the dimples on the "T" bar side of the yoke assembly and insert into the yoke.
3. Make sure the tubing is cut clean and deburred.

FLARING INSTRUCTIONS

1. Insert end of tubing into the proper size die on the clamping bar. (*O.D. sizes: 1/4, 5/16, 3/8, 1/2, 5/8 + 3/4" are marked on the clamp bar*). Tube should be approx even with the top of the clamp bar.
2. Slide the yoke assembly over the tube and align the red arrow on the yoke with the marked line on the clamp bar. Tighten the "T" handle securely to lock the yoke assembly onto the clamp bar. (*The "T" bar tip should engage with the dimple on the clamp bar*).
3. Turn the cone driving screw clockwise until a "clicking" sound is heard. The flare is now complete.
4. Turn the cone driving screw counter clockwise until cone clears the tube flare. Loosen the yoke "T" handle and slide the yoke assembly off of the clamp bar. Remove flared tube.

Ordering Information: Part No. MC70057

T: 09 636 1401 | E: sales@systemcontrol.co.nz | W: systemcontrol.co.nz

In support of our policy of continuous product improvement we reserve the right to change materials and specifications without notice. Drawings, where used, are not to scale. All dimensions are in millimetres and sizes given are approximate. Where possible, technical MSDS data sheets are made available on the website. All products should be installed and used in accordance with manufacturer's instructions provided. Warning: products may be the subject of registered designs and patents. Refer to website for terms and conditions on warranty.

SCE
SYSTEM CONTROL
ENGINEERING